

(4 1 — 3) SRAM board settings

[List of fuses]

Fuse	Current [A]	Model No.	PART CODE	Rating	Related motor
FU50	7.0		150803	7A 125V	5Vpower supply
FU51	1.0		60200158	1A 125V	TERMPower (SCSI)

※There are not mounted for FU52,FU53,and FU54.

[List of LED function]

LED No.	Light up timing	Turn off timing
1	When data for one separation is output	When transferring to the next exposure sequence
2	Unused	Unused
3	When a command interrupting exposure is sent from the MCON side during the exposure (Ex. When the STOP key is pressed)	When transferring to the next exposure sequence
4	When the page signal is activated(The "Enable bit" is turned ON)	When the page signal is negated(The "Enable bit" is turned OFF)
5	Unused	Unused
6	Unused	Unused
7	When the HOST-SPC interrupt processing is started.	When the HOST-SPC interrupt processing is finished.

These LEDs are activated, when the DIPSW1 is turned ON.

[Table of jumper settings]

Jumper	Discription	Standard
JP1	CPU function mode	1-3 short 2-4 open

※No garrantie when the jumper setting is changed except standard.

[Table of DIPSW settings]

DIPSW	Discription	Standard
1	ON : LEDs are activated、 OFF : LEDs are negated.	OFF
2	ON : Activates forced download mode、 OFF : Normal mode	OFF
3	Unused	OFF
4	ON : DIMM memory mode、 OFF : HDD emulation mode	ON
5	Unused	OFF
6	Unused	OFF
7	ON : Set the active terminator OFF (Upper byte) OFF : Set the active terminator ON (Lower byte)	OFF
8	ON : Set the active terminator OFF (Upper byte and control signal) OFF : Set the active terminator ON (Lower byte and control signal)	OFF